
Pixel Survey - Update

Problem:

- Feature finder tool cannot be used for repeated measurements => features have to be measured manually => a volunteer needed
- Carl Haber: they used an old version of MeasureMind which contained a "bug" (steps were copied with relative coordinates to preceding steps) => this bug was "fixed" in MeasureMind3D


Solution:

- We can measure a few points around the feature and create the z=0 plane => the z coordinate of the feature ~ 0.
- Repeated feature-finding steps will be performed in the z=0 height.
- If we repeat/copy all aforementioned steps, it works fine!



TPS - lambda param.

controls how much the fit can deviate
from the measured values used for the fit




A z (lambda=0.2, 54 points), NMP

∆ z (lambda=2.2, 54 points), NMP

Δ z (lambda=4.0, 54 points), NMP

3rd feature:



With 200x zoom, feature finder has sometimes difficulties to recognize it...